

# 410-e

ALGE-TIMING



## Inhaltsverzeichnis

1	ROLL MODE .....	3
2	TILT MODE .....	4
3	PAN MODE .....	5
4	Adjust to the finish line.....	6

As defined by the progress we subject to change the state of technology. You can download the newest table of contents from our homepage [www.alge-timing.com](http://www.alge-timing.com) for free.

ALGE Timy manual copyright by:

Alge-Timing


Rotkreuzstrasse 39

A-6890 Lustenau

[www.alge-timng.com](http://www.alge-timng.com)


# 1 ROLL MODE

By pressing the button ROLL, the camera goes from left to right.





## 2 TILT MODE

By pressing the button TILT, the camera goes up and down.




### 3 PAN MODE

By pressing this button, the camera goes from left to right.




## 4 Adjust to the finish line


The camera doesn't look on the finish line!



Unscrew it a little bit.



Slightly increase the gearhead.



Rotate the gearhead to left



Fix the screw.



The camera should look to the finish line now.

