

# 410-e

ALGE-TIMING



## Inhaltsverzeichnis

|   |                                |   |
|---|--------------------------------|---|
| 1 | ROLL MODE .....                | 3 |
| 2 | TILT MODE .....                | 4 |
| 3 | PAN MODE .....                 | 5 |
| 4 | Adjust to the finish line..... | 6 |

As defined by the progress we subject to change the state of technology. You can download the newest table of contents from our homepage [www.alge-timing.com](http://www.alge-timing.com) for free.

ALGE Timy manual copyright by:

Alge-Timing


Rotkreuzstrasse 39

A-6890 Lustenau

[www.alge-timng.com](http://www.alge-timng.com)


# 1 ROLL MODE

By pressing the button ROLL, the camera goes from left to right.





## 2 TILT MODE

By pressing the button TILT, the camera goes up and down.




### 3 PAN MODE

By pressing this button, the camera goes from left to right.



## 4 Adjust to the finish line

The camera doesn't look on the finish line!



Unscrew it a little bit.



Slightly increase the gearhead.



Rotate the gearhead to left



Fix the screw very gently.  
If you fix it too hard the gearhead will be damaged.



The camera should look to the finish line now.

