

## INFORMATION

## INFORMATION

## INFORMATION



### Competition:

Before a competition starts, it is necessary to loosen the four marked screw nuts (front and back side) so that the top-plate can move easily. The four screw nuts are marked by labels.

### Public operation:

The four screw nuts must be tightened **with a torque of 17 Nm** when you use the starting block for public operations (front and back side).

### Cleaning:

Occasionally, clean it with a mild cleanser in order to avoid corrosion.

### Important:

After cleaning, rinse the start block with fresh water.

## INFORMATION

## INFORMATION

## INFORMATION



### Wettkampf:

Vor dem Wettkampfstart, müssen die vier markierten Muttern (Vorder- und Rückseite) gelockert werden, so dass die Platte sich leicht bewegen kann. Die vier Muttern sind mit Aufklebern markiert.

### Öffentlicher Betrieb:

Die vier Muttern müssen mit einem **Drehmoment von 17 Nm** festgezogen werden, wenn der Startblock für den öffentlichen Betrieb benutzt wird (Vorder- und Rückseite).

### Reinigung:

Reinigen Sie den Startblock gelegentlich mit einem milden Reinigungsmittel, um Korrosion zu vermeiden.

### Wichtig:

Nach der Reinigung spülen Sie den Startblock gründlich mit sauberem Frischwasser.